

PEROXIDE PRESERVATION

This patent application claims priority from Provisional Patent Application Serial No. 60/210,969 filed June 12, 2000 and entitled "Peroxide Preservation".

This invention relates to processes and structures for packaging and preserving the cleanliness of clean room cleaning articles such as PVA sponge brushes and pre-saturated clean room wipers.

The invention includes a method of packaging PVA "rollers" (sponges) of the type shown in U.S. Patent No. 4,566,911 in a sealed package with a solution of de-ionized water and hydrogen peroxide absorbed in the sponge.

Sponges of the type here under discussion are used in the cleaning of semi-conductor wafer surfaces and other delicate surfaces to be cleaned in a clean-room atmosphere.

The sponges usually are shipped wet; that is, with pure water absorbed into the sponge material to keep it flexible. If it is not kept in a wet condition, it dries out and becomes very hard. This is deleterious to its performance in the cleaning tasks it is used for.

Traditionally, synthetic agents have been used to preserve susceptible materials, especially water-containing, and where residual contamination is not an issue, they have been

09879513.0612001

effective. Since from manufacturing to final processing of PVA (polyvinyl alcohol) can be several months, preservatives are used to prevent bacterial and mold growth which is difficult to completely remove by subsequent cleaning. The typical synthetic preservatives are also hard to remove and can serve as a potential contaminate in clean processes.

Other sterilization methods are available. These include E-beam (electron beam) and gamma radiation.

E-beam is ineffective unless each package is clearly exposed to the irradiation. Boxed lots usually would not achieve sufficient penetration to assure complete exposure of the brush. Gamma radiation is effective but much more costly and at irradiation levels for sterilization, about 25 KGY, product degradation may occur.

Some pre-saturated clean room wipers have the same problems as PVA sponges. If the cleaning solution absorbed in the wiper is not sufficiently bactericidal, bacteria can live and multiply in the package in which the wipers are contained.

PVA sponges (sponge brushes, in particular) and wipers for clean room use are subjected to severe restrictions on the quantities of impurities they can contain. These impurities include metal ions, anionic materials such as chlorides, fluorides, phosphates and bromides, and particulates.

converts it to water and oxygen ($2H_2O_2 \rightarrow 2H_2O + O_2$) compared to the hazardous decomposition products produced by other compounds, such as chlorine, chlorine dioxide, and fluorine. For this reason, it has found wide use in water treatment and medical applications. Since hydrogen peroxide is a natural metabolite of most organisms, decomposition into water and oxygen is a standard reaction they set off. In addition, UV light on water also forms hydrogen peroxide in nature which serves as a natural purification system.

Testing has shown that hydrogen peroxide can be used without irradiation, which has an adverse physical effect at sterilization levels, to provide a sterile product prior to final manufacture or for finished distribution.

It has been discovered that, by mixing hydrogen peroxide with the de-ionized water which is used to soak the sponge before shipment, bacterial growth is inhibited.

Although hydrogen peroxide is known as a bactericide, the use of hydrogen peroxide produces an unexpected benefit. This is due to the fact that the hydrogen peroxide-water solution tends to deteriorate fairly rapidly. When it does, it changes into very benign components; water and oxygen. Moreover, the deterioration does not produce any metal ions or debris of any kind which would compromise the cleanliness of the ultra-clean sponges, but does not permit bacteria to grow.

Thus, when the customer receives the product, the hydrogen peroxide will have decomposed into its benign components so that there are no chemicals to interfere with the use of the sponge in its intended cleaning process; the sponge is soaked with pure, bacteria-free water.

In actual use, in packaging PVA sponges for used in medical uses or semiconductor wafer scrubbing or other ultraclean applications, the sponge material is loaded with a mixture of very pure de-ionized water and a small percentage of hydrogen peroxide, by volume. The amount of hydrogen peroxide is selected so as to be low enough to give reasonable assurance that it will actually decompose into its components by the time the package is opened to remove the material for use.

Advantageously, the package can be a sealed plastic package of the type in which pre-saturated clean-room wipers are shipped.

In accordance with a further aspect of the invention, it has been discovered that the use of hydrogen peroxide concentrations within ranges proposed by prior users of hydrogen peroxide (e.g., 1% to 5%) can have a deleterious effect by creating unwanted impurities, such as methyl ions. Therefore, a substantially lower concentration of about 0.05 to 1%, preferably about 0.1%, is used, thereby avoiding the deleterious effects of the higher concentrations.

SECRET

IN THE DRAWINGS

Figure 2 is a perspective view of pre-saturated clean room wipers in accordance with the present invention.

Figure 1 shows a package 10 containing circular PVA sponge brush 12 and a bath of liquid (not visible but indicated at 24) surrounding the sponge 12. The bag 20 is preferably made of polyethylene, and is heat-sealed shut along one edge 22.

6

The liquid 24 is a mixture of highly pure de-ionized water and ultra-pure, semiconductor grade hydrogen peroxide, in the amount of about 0.1% by volume.

The range of usable hydrogen peroxide concentrations is from a low value sufficient to kill bacteria, believed to be around 0.05%, to a high value believed to be under or around 1%. The high value is one at which metal ions or other impurities developed are at intolerable levels. For PVA sponge, a concentration of around 0.1% is preferred.

It should be understood that the shape of the sponge 12 can vary widely. For example, it can be cylindrical, with knobs extending from the surface, or it can have one of many other shapes.

It has been found that hydrogen peroxide when supplied at concentrations within the foregoing range of values, is very likely to decompose into water and oxygen before the cleaning article is removed from the package for use. Thus, it will not be present in the PVA sponge when it is used, and the sponge will be within specifications for all contaminants.

Figure 2 shows a package 30 of pre-saturated wipers 32 in a polyethylene bag 34 which is heat-sealed along one edge ³⁶/₂₆. A central opening 38 is covered by a removable and replaceable adhesive cover 40, which can be removed to withdraw a wiper from

00879613-061204
T02190-ET964860

the package, and replaced to prevent the remaining wipers 32 from drying out.

A quantity of cleaning liquid is absorbed in the wipers. The liquid can be a solvent or other cleaning liquid, or it can be de-ionized water. If the liquid contains high concentrations of alcohol or other substances which kill bacteria, then an additional bactericide is not needed. However, if the liquid is pure de-ionized water or other non-bactericide, the addition of 0.05 to 1%, preferably 0.1%, hydrogen peroxide is effective in killing and inhibiting the growth of bacteria, in the same manner as with the PVA sponge, as described above.

The preferred material for the bag 20 and 34 is polyethylene, but any other flexible, non-reactive durable and relatively inexpensive material can be used instead.

The wipers 32 can be made of polypropylene or other suitable synthetic or natural materials.

The invention provides clean room cleaning article wet storage with a long shelf life (six months, one year and more, e.g.), without significant increase in contamination, without the cost of gamma and other irradiation or the short-comings of the other known prior techniques and materials.

The above description of the invention is intended to be illustrative and not limiting. Various changes or modifications in the embodiments described may occur to those skilled in the

art. These can be made without departing from the spirit or scope of the invention.

09879613.061204
FO2T90"ET96Z860